

Insert Panel Installation



No tools needed



Step 1



Insert Panel into one Upright channel.

Step 2



Position panel into both channels.

Step 3



Insert 4 pins. 2 pins on each side of panel. Exact pin location is not critical. Pins can be moved and/or added to accommodate shelves.

*Repeat the above process for each insert panel

Adding Shelves



Only shelves can be used with Insert Panels. Drawers, Hang-bars, rails and racks cannot be used with Insert Panels.

Use on "End" Uprights ONLY



Insert Panels can ONLY be used on the ends of assembled sections. They cannot be used on shared Uprights.

Perfect for Bookcases



Insert Panels are available on 12" and 15" deep Uprights.